

# **PYROMATE<sup>INC.</sup>**

---

## **CONGRATULATIONS !**

**"YOU HAVE PURCHASED WHAT I CONSIDER TO BE THE HIGHEST QUALITY  
CAPACITIVE DISCHARGE FIRING PANEL ON THE MARKET TODAY !  
IT'S WATERPROOF, COMPACT, DURABLE AND USER FRIENDLY."**

**DAVID M .LAVO IE**

## **OPERATING INSTRUCTIONS PRESIDENT**

**CONNECT UP TO 200 E-MATCH IN SERIES ON EACH OF TWELVE CIRCUITS.**

**TO TEST CIRCUITS CONNECT WIRES TO TERMINALS 1 THROUGH 12 AS DESIRED,  
SET SELECTOR SWITCH TO CIRCUIT 1 AND ACTUATE TEST SWITCH BELOW GREEN LED  
A LIT LED MEANS CIRCUIT IS OK, REPEAT AS NEEDED FOR REMAINING CIRCUITS**

**TO OPERATE TURN KEY TO ON POSITION DEPRESS AND HOLD ARM BUTTON, THEN  
DEPRESS FIRE BUTTON WHILE HOLDING DOWN ARM BUTTON, SWITCH TO NEXT  
CHANNEL AND REPEAT**

**WHEN RED INDICATOR LIGHT FAILS TO LIGHT OR DOES NOT LIGHT RIGHT AWAY  
IT IS TIME TO CHANGE THE 9 VOLT ALKALINE BATTERY. TO CHANGE SIMPLY REMOVE  
FACE PLATE SCREWS TO ACCESS BATTERY.**

**WARNING: NEVER LEAVE KEY IN UNIT ONCE CONNECTED TO PYROTECHNIC  
DEVICES OR WITH PERSONEL IN FIELD.**

